

Fitting Instruction

Article-No.: 118K120

Product: Adjustable Rear Set

Manufacturer : Kawasaki

Model (Type) : ZX-6R (ZX600P) 2007 - 2008

Important:

Read this instruction manual carefully and mind all warnings and tips. You should do this work only if you're qualified; otherwise we recommend this mounting to be done by a qualified workshop. Improperly mounting of this kit can reduce the driveability of the motorcycle and may be a risk to your health and life.

Special works are marked with the following signs. Please take special care on these works.



Warning! Important mounting instruction. It shows risks to your life and health.



Tips for mounting and maintenance or to avoid damage.

Fitting:

Remove stock rear sets. The following parts will be used for your new rear set: gearbox lever with ball joint, bolts to fix the stay, perhaps the right heel protector and bolts to fix the brake cylinder.



Rear sets are pre-assembled but all screws are not tightened! Always use locknuts or proper amount of medium thread-locking adhesive (e. g. Loctite 243). All details of assembling are shown on the backside drawing. All parts are welded into their bags as they belong together.



The original brake light switch has to be replaced by a hydraulic one. It replaces the banjo bolt of the brake hose at the brake cylinder. This is the highest point in the brake-system, proof proper air free installation! Use only seal rings according to the brake hose manufactures' instructions.



The original brake-hose has to be exchanged. A brake-hose with 540mm length and fittings with 20° and 20° sideward is required (LSL Article No.: 225BS54BE).

The tightening torques for connections to the frame refers to the manufacturers' instructions. Use the following torques for all the other screw connection:

M5 = 6Nm = 4.43lbf ft M6 = 10Nm = 7.38lbf ft M8 = 20Nm = 14.75lbf ft M10x1.25 = 30Nm = 22.13lbf ft




Test brake and gear shifting indoor after installing rear set. If anything is not operating properly or braking efficiency is poor, testing on the road may result in death or serious injury!

Maintenance:

Periodically proof all functions during service intervals. Use **particle free (no MoS₂)** lithium or barium soap grease to maintain lever bushings.

Advice:

If you use the upper and backward positions it is necessary to shorten the hose that connects reservoir and brake cylinder to prevent it from crushing



ULS M10×1.25×25 Schraubenprod. blocage de sécurité sicherung mittelfest z.B.: Loctite 243 p.ex. Loctite 243 medium thread locking adhesive e.g. Loctite 243 Plaque de fixation Grundplatte Hanger Utilisez rondelle de calage si le levier n'est pas mobile ggf. Paßscheibe verwenden If lever is blocked use falls Hebel nicht beweglich shim ring Rondelle / Washer Ø28mm Scheibe Ø28mm Sélecteur/pédale frein Brems- / Schalthebel Brake pedal/ Shifter Rondelle / Washer Ø25mm Scheibe Ø25mm Graisse / Grease Fett Axe de fixation starre Lagerung Journal Footpeg Fußraste Support de pieds

M5×25